

# VEF 3

Outdoor Gobo light

Function	DMX Value	Settings	10 channels	11 channels
Dimmer	000-255	0~100%	1	1
Linear and FX strobe	000-010	Strobe closed	2	2
	011-128	Fx Strobe Speed from slow to fast		
	129-255	Linear Strobe Speed from slow to fast		
color 1	0~11	White	3	3
	12~23	color 1		
	24~35	color 2		
	36~47	color 3		
	48~59	color 4		
	60~71	color 5		
	72~83	color 6		
	84~95	color 7		
	96~107	White+ color 1		
	108~119	color 1+ color 2		
	120~131	color 2+ color 3		
	132~143	color 3+ color 4		
	144~155	color 4+ color 5		
	156~167	color 5+ color 6		
	168~179	color 6+ color 7		
	180~191	color 7+White		
	192~223	Move forward: fast to slow		
	224~255	Move backward: slow to fast		
Gobo 1	0~11	white	4	4
	12~23	Gobo 1		
	24~35	Gobo 2		
	36~47	Gobo 3		
	48~59	Gobo 4		

Function	DMX Value	Settings	10 channels	11 channels
	60~71	Gobo 5	4	4
	72~83	Gobo 6		
	84~95	Gobo 7		
	96~107	Gobo 7 shaking slow to fast		
	108~119	Gobo 6 shaking slow to fast		
	120~131	Gobo 5 shaking slow to fast		
	132~143	Gobo 4 shaking slow to fast		
	144~155	Gobo 3 shaking slow to fast		
	156~167	Gobo 2 shaking slow to fast		
	168~179	Gobo 1 shaking slow to fast		
	180~191	white		
	192~223	Move forward: fast to slow		
	224~255	Move backward: slow to fast		
Gobo 2	0~11	white	5	5
	12~23	Gobo 1		
	24~35	Gobo 2		
	36~47	Gobo 3		
	48~59	Gobo 4		
	60~71	Gobo 5		
	72~83	Gobo 6		
	84~95	Gobo 7		
	96~107	Gobo 7 shaking slow to fast		
	108~119	Gobo 6 shaking slow to fast		
	120~131	Gobo 5 shaking slow to fast		
	132~143	Gobo 4 shaking slow to fast		
	144~155	Gobo 3 shaking slow to fast		
	156~167	Gobo 2 shaking slow to fast		
	168~179	Gobo 1 shaking slow to fast		
	180~191	white		
	192~223	Move forward: fast to slow		
	224~255	Move backward: slow to fast		
Gobo R	0~127	Adjust the angle	6	6
	128~191	Move forward: fast to slow		
	192~255	Move backward: slow to fast		



Function	DMX Value	Settings	10 channels	11 channels
Prism	0-80	off	7	7
	81-255	Open		
Prism R	0-63	Adjust the angle	8	8
	64-127	Move forward / backward: fast to slow		
	128-191	Clockwise rotation: fast to slow		
	192-255	Anticlockwise rotation: slow to fast		
Frost	0-80	off	9	9
	81-255	Open		
Focus	0-255	Focus	10	10
Function	000-009	No function	11	11
	010-020	Reset after 5 seconds		
	021-255	No function		

