

VLED 846

LED Par

DMX mode 1: 6CH

CH1	CH2	CH3	CH4	CH5	CH6
R (0~255)	G (0~255)	B (0~255)	W (0~255)	A (0~255)	I (0~255)

DMX mode 2: 8CH

CH1	CH2	CH3	CH4	CH5	CH6	CH7	CH8
Dimmer	R	G	B	W	A	I	STROBE
0~255	0~255	0~255	0~255	0~255	0~255	0~255	0~255

DMX mode 3: 10CH

CH1	CH2	CH3	CH4	CH5	CH6	CH7	CH8		CH9		CH10
Dimmer	R	G	B	W	A	I	Program		Speed		Strobe
0~255	0~255	0~255	0~255	0~255	0~255	0~255	CH1-6	0			0~255
							Pr. 01	1-20	OFF	0	
									R	1~16	
									G	17~33	
									B	34~50	
									W	51~67	
									A	68~84	
									I	85~101	
									RG	102~118	
									RG	119~135	
									RB	136~152	
									RB	153~169	
									GB	170~186	

DMX mode 3: 10CH

CH1	CH2	CH3	CH4	CH5	CH6	CH7	CH8		CH9		CH10	
0-255							Pr.01	1-20	RW	187~203	0-255	
									GW	204~220		
									BW	221~237		
									WW	238~254		
									CW	255		
							Pr.02	21~41	Program Speed 0~255			
							Pr.03	42~62				
							Pr.04	63~83				
							Pr.05	84~104				
							Pr.06	105~125				
							Pr.07	126~146				
							Pr.08	147~167				
							Pr.09	168~188				
							Pr.10	189~209				
							Pr.11	210~230				
							Pr.12	231~251				
							Sound	252~255				

