

VLED 934

LED Par

DMX mode 1: 4CH

CH1	CH2	CH3	CH4
R(0~255)	G(0~255)	B(0~255)	W(0~255)

DMX mode 2: 6CH

CH1	CH2	CH3	CH4	CH5	CH6
R(0~255)	G(0~255)	B(0~255)	W(0~255)	Dimmer(0~255)	Strobe(0~255)

DMX mode 3: 8CH

CH1	CH2	CH3	CH4	CH5	CH6		CH7	CH8
Dimmer	R	G	B	W	Program		Speed	Strobe
0-255	0-255	0-255	0-255	0-255	CH2-5	0		0-255
					Pr. 01	1-24	OFF (0-18)	
							R (19-37)	
							RG (38-56)	
							RG (57-75)	
							G (76-94)	
							GB (95-113)	
							B (114-132)	
							RB (133-151)	
							RB (152-170)	
							W (171-189)	
							RW (190-208)	
							GW (209-227)	
							BW (228-246)	
							RGBW (247-255)	

DMX mode 3: 8CH

CH1	CH2	CH3	CH4	CH5	CH6		CH7	CH8
0-255	0-255	0-255	0-255	0-255	Pr.02	25-49	0-255	0-255
					Pr.03	50-74		
					Pr.04	75-99		
					Pr.05	100-124		
					Pr.06	125-149		
					Pr.07	150-174		
					Pr.08	175-299		
					Pr.09	200-224		
					Pr.10	225-249		
					Sound	250-255		

